



Part Number: 11546.01
TJ Rear Rock Bumper
Installation Instructions

1. Remove the rear stock bumper and keep lower mounting hole bolts.
2. Install new Omix rear rock bumper on vehicle.



Note: Use supplied 3/8" bolts with lock washers in all 8 upper cross member mounting locations. Torque bolts between 30-35 ft lbs. reuse lower stock mounting bolt an torque between 40-45 ft lbs. Some TJ models may not have full 8 upper mounting holes in the vehicles rear frame cross-member. If vehicle does not have all 8 mounting holes than used the measurements below to drill the additional 4 holes at points indicated. Drill the frame cross-member holes to 7/16". See **Figure A**

(Fig. A) Frame Cross-member mounting location.

