

## Jeep® JK Center Console Arm Rest Installation Instructions 2007-08

- Contents:**
- (1) Arm Rest Frame (Metal)
  - (1) Arm Rest Pad
  - (4) Mounting Screws - Pad
  - (4) Black Plastic Spacer
  - (4) Frame Mounting Screws



1. Please read instructions fully prior to installing the JK Center Console Arm Rest (13107.XX). The arm rest has been designed to be a no drill application for ease of installation. Take your time when installing to avoid scratching the plastic OE vehicle console cover. The arm rest when properly installed will just touch the top of the console.

2. Open console lid and remove the rear 4 torx head screws. (use a T20 torx bit). Retain these 4 screws as they will be reused later. Remove console lid.
3. With console lid removed unscrew the 4 side torx head screws using the same T20 torx bit.
4. Place Arm Rest over console lid being careful not to scratch plastic cover.
5. Place black plastic spacers between arm rest and console as shown. Secure with longer phillips head screws supplied.
6. Repeat step 5 for other three mounting points.
7. Place console lid and arm rest back onto lower console and secure using the 4 torx head screws saved from step 2.



Step 2



Step 2-3





### Care Instructions and Warranty Information

8. Denim fabric can be cleaned using warm water and mild soap. The Neoprene pads can be pre-treated with 303 fabric protector making sure to test a small area before applying to insure no fading will take place. It is important to note that Neoprene will fade if placed in direct sunlight for an extended period. Regular cleaning using warm water and a very mild soap will also help to maintain the Neoprene's appearance. DO NOT scrub Neoprene when cleaning. This will cause fading.

RUGGED RIDGE - OMIX does not sell listed 303 fabric protector. This product can be sourced from a boating supply house or fabric store.

#### LIMITED 90 DAY WARRANTY Applies to Rugged Ridge - Outland Automotive by Omix-Ada Inc. Products

Rugged Ridge - Outland Automotive and OMIX - ADA (the company) warrants to the original purchaser of this product that should the product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 90 DAYS from the date of original purchase, such defect(s) will be repaired or replaced or credited at the Company's sole option.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. Dated bill of sale), specification of defect(s) to the place of purchase or, with prior approval from the Company (Return Authorization Number is required), freight pre-paid to the Company address listed below.

This warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident or by acts of nature. THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN THE PERIOD OF 90 DAYS FROM DATE OF ORIGINAL PURCHASE.

IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Omix-Ada Inc.  
460 Horizon Dr. Suite 400  
Suwanee, Georgia 30024

